

Box Maker - Generic Generator

The image shows two screenshots of the 'Box Maker - Generic Generator' software interface. The top screenshot displays the 'Box dimensions' tab, and the bottom screenshot displays the 'Round corners' tab.

Box Maker - Generic Generator

Box dimensions | Round corners | Lid style | Internal slots | Joints

Einheit

External dimensions for the box

width	<input type="text" value="80,0"/>	-	+
depth	<input type="text" value="80,0"/>	-	+
height	<input type="text" value="80,0"/>	-	+
thickness of material	<input type="text" value="4,0"/>	-	+
Burn factor	<input type="text" value="0,1"/>	-	+

Vorschau

Schließen Anwenden

Box Maker - Generic Generator

Box dimensions | **Round corners** | Lid style | Internal slots | Joints

Straight corners

If not straight corners, radius of each corner

Back left radius	<input type="text" value="25,0"/>	-	+
Back right radius	<input type="text" value="25,0"/>	-	+
Front left radius	<input type="text" value="25,0"/>	-	+
Front right radius	<input type="text" value="25,0"/>	-	+

Vorschau

Schließen Anwenden

Box Maker - Generic Generator

Box dimensions Round corners **Lid style** Internal slots Joints

Lid style Without lid

Only used with real lid

Lid height 20,0 - +

Only used with coffin lid

dome lid height 20,0 - +

Skip flex lines when possible

Vorschau

Schließen Anwenden

Box Maker - Generic Generator

Box dimensions Round corners Lid style **Internal slots** Joints

Anzahl der Spalten 2 - +

Anzahl der Zeilen 1 - +

Vorschau

Schließen Anwenden

Box Maker - Generic Generator


Box dimensions Round corners Lid style Internal slots **Joints**


Finger size computed from box dimensions

Finger size for joints in X direction 5,0 - +

Finger size for joints in Y direction 5,0 - +

Example Output





Version #1

Erstellt: 2025-05-24 15:17:09 CEST von Mario Voigt

Zuletzt aktualisiert: 2025-05-24 15:17:59 CEST von Mario Voigt